



Silver Bullet

Throttle Body Spacer

PN 46-34011

INSTALLATION INSTRUCTIONS

Year	Make	Model	SubModel	Engine	Fuel
2016-2019	Chevrolet	Camaro SS		V8 6.2L	Gas
2014-2019	Chevrolet	Corvette	(C7) Stingray	V8 6.2L	Gas

1. Disconnect the two crankcase hoses from the air intake tube. Using an 8mm nut driver, loosen the two hose clamps on the intake tube. Remove the intake tube from the vehicle.
2. Disconnect the wiring harness at the throttle body. Using a 10mm socket and driver, remove the four (4) screws securing the throttle body. Set the throttle body and the four (4) screws aside.
3. Slide the *aFe Silver Bullet* throttle body spacer and orient it with the word "TOP" facing out and up. Place the gasket in-between the throttle body spacer and the throttle body.
4. Use the four (4) factory screws previously removed to secure the throttle body to the intake manifold. Torque the screws to 88 in/lb. DO NOT OVERTIGHTEN THE BOLTS!
5. Reinstall the intake tube, tighten the two clamps, and reconnect both of the crankcase hoses.



PARTS LIST

- 1 *aFe Silver Bullet* spacer
- 1 gasket

TOOLS NEEDED

- 8mm nut driver
- 10mm socket & driver

advanced FLOW engineering, Inc.

252 Granite Street, Corona, CA 92879

For TECHNICAL and INSTALLATION SUPPORT, please call 951-493-7134 OR email Tech@afepower.com (send photos if helpful)

For all other types of calls, please use our main line at 951-493-7100

www.aFePower.com

Revised: 06/27/2019 kat