



# Installation

**Kit P/N:**

TR-1009P (Polished)  
TR-1009B (Wrinkle Black)

**Make:**

Acura

**Model:**

RSX Type S (DC5)

**Year:**

'02-'06

**Engine:**

L4-2.0L

**Parts Identification:**

- 1 Air filter ( Pro Dry S™ TF-9004D)
- 1 Intake tube, 05-T1009P1
- 1 Coupling, straight 05-01107
- 2 Clamp #044
- 1 5/8" Hose @ 4"L
- 1 Flat washer, M6
- 1 Screw hex, M6 x 1 x 16
- 1 Grommet

**Tools Required:**

- 10mm socket or wrench
- 8mm socket or wrench
- Ratchet w/ extension
- Phillips screw driver
- Flat head screw driver
- 5/16" nut driver

*Note: Read instructions before installation and have tools ready.*



Loosen clamp on air box using 10mm socket or wrench and disconnect temp sensor harness.



Pull back crank case line from air box and remove.



Complete Stock intake. Please disconnect battery terminals before installation.



Remove stock intake tube.



Remove upper half of air box assembly.



With 10mm socket or wrench loosen clamp on throttle body.



With 10mm socket or wrench loosen clamp on throttle body. With 10mm socket or wrench loosen the 3 bolts holding in air box.



Remove bottom half of air box assembly.





# Accessories



Replacement Filter P/N:  
TF-9004D



Pre Filter P/N:  
TP-7011B

Note: Filter Cleaning: When cleaning your **Pro Dry S™** filter, be sure to use only "Restore Kit" (Takeda P/N: TP-7015C Pro Dry S™ cleaner only.)

**Pro Dry S™** cleaning:  
see cleaning instruction sheet TF-9000I.

For replacement part(s) or "Restore Kit" please log on to [takedausa.com](http://takedausa.com)  
P.O. Box 1719 Corona CA, 92878



10 Remove temp sensor from stock intake tube.



11 Attach coupler to tube using clamps provided. Do not tighten. Install grommet to hole on tube.



12 Install intake assembly and position. Do not tighten.



13 Tighten clamps using 5/16" nut driver.



14 Secure tab on tube to engine. Tighten using provided screw and flat washer.



15 Install temp sensor to grommet on tube and connect sensor harness.



16 Reinstall the crank case line using the provided 5/8" hose.



17 Attach air filter to tube and tighten using 5/16" nut driver. Re-connect battery terminals.



18 Your installation is now complete. Please check all components and re-tighten if necessary. Thank you for choosing Takeda!  
Place the included CARB EO sticker on or near the device on a smooth, clean surface. E.O. Identification is required in passing the smog check inspection.