



ORIENTATION OF FRICTION DISC

READ BEFORE FITTING

This kit is a conversion from dual mass flywheel to single mass flywheel and requires the friction disc to be oriented with the spring cage facing toward the transmission.

Failure to assemble the friction disc in this orientation will cause damage to the transmission and the clutch.



CORRECT ORIENTATION



INCORRECT ORIENTATION



IFANING RRANDS





