

This instruction is for both left front (driver) 41-269282 and right front (passenger) 41-269299 B8 8112 shocks. A step by step process is shown with images of the right front. The left front is a mirror image of the right front. Skip to the end to see final result.

A bill of materials of the included mounting part kits is shown on the next page.

#### IMPORTANT! READ THIS FIRST!

Installation of shock absorbers requires special tools and expert knowledge. Accordingly, installation of all BILSTEIN products must be performed by a qualified suspension specialist.

When replacing other brands, BILSTEIN shock absorbers should always be installed as a set. All BILSTEIN products must only be used for the specific, intended application as indicated in the application guide. Any use of any BILSTEIN product other than for its intended use may result in serious bodily injury or death.

Always use a chassis hoist for the installation of BILSTEIN products and make certain that the raised vehicle is securely attached to the hoist and/or supported to prevent the vehicle from slipping, falling, or moving during the installation process.

If you choose to install any BILSTEIN product without the necessary special tools, expertise or chassis hoist, you may subject yourself to the risk of serious bodily injury or death. If you elect not to use a chassis hoist, at least make sure the vehicle is on level ground, that all tires on the ground during installation are blocked to prevent movement, that at least two tires are on the ground at all times, and that adequately secured safety stands (jack stands) are used to support the chassis. <u>NEVER</u> get under the vehicle until you have checked to make sure all of these steps are performed.

BILSTEIN suspension products are gas-filled and are highly pressurized.

- Never place any BILSTEIN product in a vise or use a clamp on any BILSTEIN product.
- Never apply heat near any BILSTEIN product.
- Never attempt to open or repair any BILSTEIN product, in order to prevent serious bodily injury or death.

Any attempt to misuse, misapply, modify, or tamper with any BILSTEIN suspension product voids any warranty and **may result in serious bodily injury or death.** 


While installing any BILSTEIN product:


- Do not use impact tools for loosening or tightening fasteners, because this may destroy the screw threads.
- Self-locking fasteners must only be used **once**!
- Reuse original equipment components only if they are in good condition, otherwise replace them with new components.
- Never remove the slight film of oil on the piston rod and seal.
- All mounting fasteners for shocks and struts must be securely tightened before the vehicle is operated.


After installing any BILSTEIN product:

- The suspension caster and camber must be checked and/or adjusted to comply with the vehicle manufacturer's specifications.
- The (load dependent) brake compensator and the anti-lock brake system must be checked and/or reset to comply with the vehicle manufacturer's specifications.
- The headlight aim must be checked and adjusted.











B8 8112 shocks feature a proprietary BILSTEIN zinc plated finish. This finish must be serviced in order to maintain its luster. Particularly in moist climates, a protective coating, such as a wax or lubricating oil should be periodically applied to prevent tarnishing. This finish is not covered under warranty.

It is normal to hear a slight audible clicking noise during compression and rebound strokes in the B8 8112 shocks, most notably during low velocity events. This is due to the internal pistons engaging each other creating the position sensitive compression and rebound zones.

#### B8 8112 shock installation procedure:

- A. Remove the existing shock module from the vehicle following all procedures in the vehicle manufacturer's service manual. Save the lower shock bolt and nut as they will be used later.
- B. Before installing the B8 8112 shocks on the vehicle check if they are set at the desired lift height. The pre-set lift heights are different for each drive-type, engine, cab, bed, and year range. Use the tables below to determine if the pre-set lift height is what is desired:


	VD V6, Cab, 6' Bed	D	4WD V6, Double Cab, 5' Bed		4WD V6, Access Cab		4WD 4cyl, Access Cab
2016+	2005-2015	2	2016+	2005-2015	2016+	2005-2015	2016+
1.4" lift	1.9" lift	1	.5" lift	2.2" lift	1.6" lift	2.1" lift	1.6" lift

	6 lug, V6, Cab, 6' Bed	,	RWD, 6 lug, V6, Double Cab, 5' Bed		RWD, 6 lug, V6, Access Cab		RWD, 6 lug, 4cyl, Access Cab
2016+	2005-2015	2016+	2005-2015		2016+	2005-2015	2016+
1.7" lift	2.1" lift	2" lift	2.3" lift		2.2" lift	2.6" lift	Do not use

Note that the pre-set lift height is too high for a 2016+ RWD, 6 lug, 4cyl, Access Cab and must be adjusted before installing on vehicle. Proceed to Step D for instructions on how to lower spring seat.

- C. If the lift height listed above is not what is desired, proceed to Step D. Otherwise, go to Step K.
- D. Break the spring seat lock ring loose with the supplied spanner wrenches. Refer to Figure 1 on the next page.
- E. Note the clocking of the lower mount relative to the studs on the upper mount (important for reassembly).
- F. Using an appropriate spring compressor, compress the spring until it can be rotated freely by hand. Then, spin the spring seat up or down depending on what the desired lift height is. Note that the right side (passenger) should always be approximately 5/16" lower than the left side (driver) to compensate for the inherent vehicle lean. The following tables show what the allowable lift height ranges are for each truck configuration and give a few points of reference for the relationship between the amount of exposed thread and the estimated lift height. They are listed for stock weight vehicles.





#### DO NOT EXCEED MAX LIFT HEIGHT LISTED FOR YOUR VEHICLE

4WD V6, Double Cab, 6' Bed				
Exposed	Threads	B8 8112 Typical Lift Heights**		
Left Front	Right Front	2016+	2005-2015	
1 9/32" (very top)	31/32"	2" lift	2.5" lift	
31/32"	21/32"	1.5" lift	2" lift	
5/8"	11/32"	1" lift	1.5" lift	
5/16"	0"	0.4" lift	0.9" lift	

4WD V6, Access Cab				
Exposed	Threads	B8 8112 Typical Lift Heights**		
Left Front	Right Front	2016+	2005-2015	
1 1/8"	13/16"	2" lift	2.5" lift	
7/8"	9/16"	1.5" lift	2" lift	
19/32"	9/32"	1" lift	1.5" lift	
5/16"	0"	0.6" lift	1.1" lift	

RWD, 6 Lug, V6, Double Cab, 6' Bed				
Exposed	Threads	B8 8112 Typical Lift Heights**		
Left Front	Right Front	2016+	2005-2015	
1 3/32"	25/32"	2" lift	2.4" lift	
27/32"	17/32"	1.6" lift	2" lift	
9/16"	1/4"	1.2" lift	1.6" lift	
5/16"	0"	0.8" lift	1.2" lift	

RWD, 6 Lug, V6, Access Cab				
Exposed	Threads	B8 8112 Typical Lift Heights**		
Left Front	Right Front	2016+	2005-2015	
29/32"	19/32"	2.2" lift	2.6" lift	
5/8"	5/16"	1.7" lift	2.2" lift	
5/16"	0"	1.2" lift	1.7" lift	

4WD V6, Double Cab, 5' Bed				
Exposed	d Threads	B8 8112 Typical Lift Heights**		
Left Front	Right Front	2016+	2005-2015	
1 7/32"	29/32"	2" lift	2.6" lift	
29/32"	19/32"	1.5" lift	2.2" lift	
5/8"	5/16"	1" lift	1.7" lift	
5/16"	0"	0.5" lift	1.3" lift	

4WD 4cyl, Access Cab				
Exposed	d Threads	B8 8112 Typical Lift Heights**		
Left Front Right Front		2016+		
1 1/8"	13/16"	2" lift		
7/8"	9/16"	1.5" lift		
19/32"	9/32"	1" lift		
5/16"	0"	0.6" lift		

RWD, 6 Lug, V6, Double Cab, 5' Bed				
Exposed	d Threads	B8 8112 Typical Lift Heights**		
Left Front	Right Front	2016+	2005-2015	
1"	11/16"	2.2" lift	2.5" lift	
21/32"	11/32"	1.6" lift	2" lift	
5/16"	0"	1" lift	1.5" lift	

RWD, 6 Lug, 4cyl, Access Cab				
Exposed	d Threads	B8 8112 Typical Lift Heights**		
Left Front Right Front		2016+		
19/32"	9/32"	2.2" lift		
5/16"	0"	1.7" lift		




\*\* Lift heights indicated are typical. Actual lift height is influenced by which factory suspension the vehicle is equipped with and its condition; optional equipment and accessories on your vehicle, and other vehicle modifications such as replacement coil springs, wheel and tire combinations, etc.

Modifying/lifting the suspension to your vehicle may raise its center of gravity and may make it more susceptible to loss of control and/or rollover, which may result in death or serious injury. We strongly recommend that you offset the loss of rollover resistance as much as possible by increasing tire track width, and that you equip the vehicle with a functional roll bar and cage system.

Wear seat belts and shoulder harnesses at all times, and avoid situations where a side rollover may occur.

NOTE: if you exceed the recommended spring seat adjustment range (exposed thread dimension) for your vehicle, make sure to measure the shock at ride height as shown below after the install. This is needed to insure there is at least 2" of droop travel from static ride height and so the stiffer rebound zone is not being engaged at ride height.



Left Front (driver) depicted

- G. Before finalizing the desired lift height, position the elongated hole in the spring seat so it will face inboard once installed on the vehicle.
- H. Once the desired lift height is set, tighten lock ring against spring seat using supplied spanner wrenches.

#### Torque lock ring to spring seat 37 ft-lb (50 Nm).

- I. Rotate the lower shock mount so it is aligned with the upper mount studs as noted in step E.
- J. Slowly release the spring compressor.



K. Disconnect the sway bar bolts holding sway bar to frame (2 per side) with a 14mm socket and drop the sway bar as shown in the images below. Save these bolts as they will be used to mount the new sway bar spacers later.



L. Install the shock onto the vehicle as shown in the image below. Use the 6 supplied nuts and a 15mm socket to attach the upper mount (3 per side, BOM item #4). Leave reservoir hanging temporarily. **Torque supplied upper mount nuts to service manual specification.** 



M. Attach the lower shock mount with the OE shock bolt and nut that was removed in Step A (1 per side). **Torque lower OE shock bolt and nut to service manual specification.** 



N. Apply non-permanent thread locker on the end of each of the screw threads of the OE sway bar bolts that were removed in Step K. Then place these bolts through the counterbore'd holes in the supplied sway bar spacer (BOM item #6) and thread into the threaded holes in the frame using a 14mm socket (2 per side) as shown in the image below.

Torque OE sway bar bolts to service manual specification.





O. Apply non-permanent thread locker on the end of each of the screw threads of the 4 supplied M10 Flange Head Cap Screws (BOM item #3). Then place these screws through the holes in the OE sway bar bracket and thread into the threaded holes in the supplied sway bar spacer with a 15mm socket (2 per side) as shown in the 2 images below.

Torque supplied M10 Flange Head Cap Screws to 37 ft-lb (50 Nm).








E4-WM5-Y542A00\_0 Page 8 of 15



- P. Apply non-permanent thread locker on the end of each of the screw threads of the 4 supplied M8 Flange Head Cap Screws (BOM item #8). Then place these screws through the holes in the supplied reservoir support plate (BOM item #5) and thread into the threaded holes in the supplied reservoir clamp (BOM item #7) as shown in the depictions below using a 13mm socket (2 per side). Torque supplied M8 Flange Head Cap Screws to 18 ft-lb (25 Nm).
- Q. Apply non-permanent thread locker on the end of each of the screw threads of the 2 supplied Socket Head Cap Screws (BOM item #9). Place the Socket Head Cap Screw up through the pinch bolt hole in the reservoir clamp as shown in the depictions below and thread in with a 5mm hex key (1 per side). Thread it in enough so the Socket Head Cap Screw won't fall out, but loose enough so you can still slide the clamp onto the reservoir in the next step.









R. Slide reservoir clamp (with support plate attached) over the reservoir in the direction shown in the image below.





S. Apply non-permanent thread locker on the end of each of the screw threads of the 4 supplied M10 Flange Head Cap Screws (BOM item #3). Then install the reservoir support plate assembly to the sway bar spacer as shown in the image below by placing these screws through the holes in the reservoir support plate and threading them into the threaded holes in the sway bar spacer with a 15mm socket (2 per side). Torque supplied M10 Flange Head Cap Screws to 37 ft-lb (50 Nm).

T. Slide the reservoir until the bracket is approximately in the center of the reservoir.

U. Tighten the Socket Head Cap Screw that was partially threaded in on Step Q with a 5mm hex key. Torque Socket Head Cap Screw to 6 ft-lb (8 Nm).



V. Re-attach and torque outer tie rod, control arm to knuckle ball joint nut, and sway bar link according to service manual specifications.

created: 01.08.18

E4-WM5-Y542A00\_0 Page 11 of 15



- W. Using the 3 provided zip ties, relocate the ABS line that is attached to the bracket on the upright knuckle as shown in the following steps (same process on other side). Be careful to not damage the ABS line during this process.
- X. Clip and remove the OE zip tie shown in the image below (circle #1) and remove ABS line from bracket (circle #2).



Y. Move ABS line to outer side of bracket as shown in the image below and secure it with the 1st supplied zip tie (circle #3). Trim excess zip tie length after installation. Install the 2nd supplied zip tie as shown (circle #4). Pull tight and trim excess zip tie length after installation.





Z. Secure the upper portion of the ABS line using the 3rd supplied zip tie. Loop it through the 2nd zip tie that was installed previously as shown in the image below (circle #5). Trim excess zip tie length after installation.



AA. Once the ABS line has been relocated as shown above, the installation is complete.

BB. Check wheel alignment and adjust to the vehicle manufacturer's specifications.



Final right front (passenger) B8 8112 shock installed on vehicle:



Aftermarket upper control arm is pictured. The B8 8112 system will also work with OE upper control arms.



Final left front (driver) B8 8112 shock installed on vehicle:



Aftermarket upper control arm is pictured. The B8 8112 system will also work with OE upper control arms.