



Intake Kit Installation Instructions: Jeep Wrangler TJ 97-02 L4-2.5L Stage-2 Air Intake

advanced FLOW engineering™
 P.O. Box 1719
 Corona, CA 92878
 Support: 951-493-7100
 aFepower.com

Kit P/N:	51/54/75-11832		
Make:	Jeep		
Model:	Year:	Engine:	
Wrangler	97-02	L4-2.5L	

Tools Required:
5/16" nut driver
1/4" nut driver
Flat head screwdriver
8MM socket or wrench
10mm socket or wrench
Ratchet w/extension

Parts List:	
1 Air filter (Pro-5R™ 24-30018 or Pro Dry S™ 21-30018 Pro-GUARD 7™ 72-30018)	2 Nut M6 (03-50059)
1 Housing (05-00086)	2 Washer, wavy M6 (03-50058)
1 Coupler, elbow (05-00395)	2 Screw, hex M6 (03-50057)
1 Coupler, straight (05-00570)	2 Clamp, #044 (03-50019)
1 Tube, intake wrinkle black (05-01082)	2 Clamp, #048 (03-50007)
1 3/4" trim seal @ 25.5 "L (05-00007)	1 Grommet, rubber (03-50076)
4 Washer, flat fender (03-50074)	2 Mini clamp, #008 (03-50077)
	1 5/8" hose @ 7.5L" (05-00069)



Step 1
Complete Stock Intake.
 Disconnect battery before install.



Step 2
 Loosen clamp on stock intake using 5/16" nut driver.



Step 3
 Loosen clamp on throttle body using 5/16" nut driver.



Step 4
 Loosen bolts holding in stock intake tube on valve cover using 8mm socket or wrench and remove.



Step 5
 Pull crank case line away from stock intake and remove from vehicle.



Step 6
 Loosen bolt on core support bracket using 13mm socket or wrench.



Step 7
 Remove upper half of air box. Loosen the 3 bolts on bottom of air box using 8mm socket or wrench and remove.




Step 8
 Attach grommet provided and install on core support bracket.



Step 9
 Loosen bolt on core support using 10mm wrench. Save bolt for later install.



Step 10
 Attach trim seal to housing and install. Make sure core support bracket slides through hole on housing.



Step 11
A) Top view: Secure housing using hex screws, fender washers, wavy washers and nuts. **B) Bottom view:** Tighten using 10mm socket or wrench.



Step 12
 Align grommet from step 8 and position in hole to prevent core support bracket from vibration.



Step 13
 Secure core support bracket using 13mm.



Step 14
 Secure bracket on housing using screw from step 9 using 10mm wrench.



Step 15
 Remove crank case line from engine.

Turn page over and continue to page 2 →



advanced FLOW engineering™
P.O. Box 1719
Corona, CA 92878
Support: 951-493-7100
aFepower.com

Intake Kit Installation Instructions: 51/54/75-11832 Stage-2 Air Intake

Accessories Available:




Restore Kits

90-50001 Blue Aerosol
90-50501 Blue Squeeze
90-59999 Pro Dry S™ Cleaner



Pre-filter 28-1008x



Replacement Air Filter:



Pro-5R™ 24-30018 Blue Media



Pro Dry S™ 21-30018 White Media

Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50001 blue oil aerosol, aFe P/N: 90-50501 blue squeeze bottle oil, aFe P/N: 90-59999 Pro Dry S™ cleaner only.) Pro Dry S™ cleaning: see cleaning instruction sheet 06-00074. For replacement part(s) or "Restore Kit" please call aFe sales/tech support @ 951-493-7100

Step 16



Attach elbow coupling with #048 clamps to housing and position. Do not tighten.

Step 17



Attach straight coupling with #044 clamps provided on end of intake tube and position to housing and throttle body.

Step 18



Reinstall crankcase line using the supplied 5/8" hose and mini clamps and attach to engine and intake tube. Secure mini clamps using 1/4" nut driver.

Step 19



Install air filter and tighten all clamps using 5/16" nut driver. Reconnect battery terminals.

Step 20



Your installation is now complete. Make sure to check all hoses and tighten any clamps or hardware if necessary. Thank you for choosing aFepower.
Place enclosed CARB EO sticker on a clean/smooth surface on or near the intake system.
EO identification label is required in passing a smog check inspection.