


INSTALLATION INSTRUCTIONS 14" X-Stream Custom Assemblies Part # 66-3000, 66-3010, 66-3020, 66-3030, 66-3040, 66-3050, 66-3060, 66-3070, 66-3080, 66-3090, 66-3100

Congratulations, you have purchased the finest air intake kit that money can buy. The following procedure MUST be followed to ensure proper performance and seal of the K&N[®] X-Stream[®] Custom Assembly. Failure to follow any of these steps CAN result in the X-Stream's top warranty becoming void

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

CAUTION: It is imperative that no part of the X-Stream[®] top comes into contact with anything on the vehicle at any time. If the X-Stream[®] top rubs against anything it might become irreparably damaged. Double check measurements to verify that no interference will occur **BEFORE** closing the hood.

- **Step 1** Thread the all-thread stud into the carburetor until it bottoms out. Secure with jam nut.
- **NOTE:** If your carburetor has a 5/16" x 18" stud boss, use the provided 5/16 to 1/4" adapter.
- Step 2 Install the neoprene gasket and the base plate on carburetor.
- Step 3 Install the K&N[®] air filter making sure it is fully seated in base.
- Step 4 Thread one of the nylock nuts onto stud.
- Step 5 Place a straight edge across the top of the air filter element. Adjust the nylock until the top of it is 3 turns below the bottom of the straight edge.
- **Step 6** Remove the stud and cut it 1-1/4" above the nylock. De-burr the end of the stud and make sure the nut threads on smoothly.
- Step 7 Re-install the stud making sure the nylock is still 3 turns below the straight edge.
- Step 8 Place one of the steel washers on the stud.
- **Step 9** Install the X-Stream[®] Air Flow Top making sure it is fully seated on the air filter all the way around.
- Step 10 Install rubber washer.
- Step 11 Install steel washer.
- Step 12 Install nylock nut It should become tight 1-1/2 to 2 turns after contacting the flat washer.



US PATENT Number: D401,597